

KOPFJÄGER

**DIRECT MOUNT
ADAPTER**



**HEAVY DUTY
CONSTRUCTION**



USER MANUAL

KJ89003

KOPFJÄGER DIRECT MOUNT ADAPTER USER MANUAL

Designed specifically for use with the Kopfjäger Reaper Grip, the Direct Mount Adapter (compatible with Arca Swiss mounts) reduces the overall size and weight of our shooting rest system and gives you the versatility to direct mount the Reaper Grip upper assembly to tripods with ball/leveling heads. The Arca Swiss-compatible direct mount fits best on tripods with a 3/8"-16 threaded screw and center column that allows rotation for horizontal panning. A 1/4"-20 adapter is provided for tripods or quick-release plates. Note: Vertical movement is limited but can be achieved by loosening the tightness of the Reaper Grip.

MOUNTING

The Kopfjäger Direct Mount installs directly underneath your Reaper Grip upper assembly.

- 1) Loosen the Reaper Grip upper assembly's grip knob by turning counter-clockwise. Continue turning until the knob is out of adjustment and the pivoting grip is opened as wide as possible.
- 2) Place the top of the Direct Mount Adapter under the bottom of the Reaper Grip upper assembly's base plate, ensuring the adapters channel is parallel to the direction of the fixed side of the Reaper Grip. Align the two screw holes nearest the fixed side of the Reaper Grip.
- 3) Install two Phillips-head screws down through the top of the Reaper Grip base plate and into the top of the Direct Mount Adapter. (Do not tighten yet.)
- 4) Swiveling the pivoting side of the Reaper Grip will reveal the opposite-side screw holes individually. Swivel the pivoting side of the grip to expose one screw hole and install a Phillips-head screw down through the Reaper Grip base plate into the top of the Direct Mount Adapter. (Do not tighten yet.)
- 5) Swivel the pivoting side of the grip to expose the last screw hole. Repeat step 4. (Do not tighten yet.)
- 6) Tighten the four mounting screws in a star pattern.
- 7) Re-tighten the Reaper Grip adjustment knob to the desired width.

WARNING

Before handling the Direct Mount, read and understand the contents of your Direct Mount's manual, as well as the manuals for your Reaper Grip and tripod.

- Do not exceed the tripod's maximum load capacity. (see your tripod manual.)
- Ensure the direct mount is fastened and mounting screws are tight.
- Always remove firearms or accessories before transporting.

SPECIFICATION:

GENERAL DESCRIPTION	
Brand Name	Kopfjäger
Model Name	Direct Mount Adapter
Category Name	Accessories
SKU Number	KJ89003
UPC Number	812495026195
TECHNICAL SPECIFICATIONS	
Dimensions, in/mm	2 x 2 x 1.13 / 51 x 51 x 28.7
Material	Aluminum
Weight, lbs/g	.2/90
FEATURES	
	Can Mount Reaper Grip to ball head tripod
	Works only with Reaper Grip

NOTES:
